

Base



Base/plinth adaptor

for twin castors and levelling feet

For mounting twin castors and levelling feet to the base/plinth.

| Material | P. of | Model No. |
|-----------------|----------|-----------------|
| Sheet steel | 4 pc(s). | 8100.770 |
| Stainless steel | 4 pc(s). | 8100.771 |

Note:

- When fitting twin castors, side trim panels, see page 86, are required.



System divider

Divides the enclosure width into two zones. In this way, for example, mounting plates, cable clamp rails or swing frames from 600 mm wide enclosures can be fitted in 1200 mm wide enclosures.

| Depth | P. of | Model No. |
|-------|----------|-----------------|
| 500 | 2 pc(s). | 8620.900 |
| 600 | 2 pc(s). | 8620.901 |

Material:

- Sheet steel

Surface finish:

- Zinc-plated

Supply includes:

- Assembly parts



Accessories:

- Swing frame mounting kit, see page 194
- Cable clamp rail, see page 187
- Support rails 48 x 26 mm, see page 152

